


SB-390 CABLING

1. SHORT CABLE FOR INSTALLATION INSIDE RADIO:
CUT 7" STRANDED #24 WIRE (RED, BLACK, WHITE)
STRIP ONE END 3/16". CRIMP MALE MOLEX PINS.
INSERT IN CONNECTOR IN ORDER



2. BFO & POWER CABLE

CUT COAX AND #24 RED STRANDED WIRE
TO 26".

STRIP & CRIMP ON FEMALE MOLEX CONNECTOR PINS.
PULL COAX CONDUCTOR OUT THRU SIDE OF BRAID.
~~INSERT~~

STRIP OTHER ENDS FOR BOARD.

INSERT CONNECTOR PINS INTO BODY.

PIN 1 (V) IS COAX CENTRE CONDUCTOR.

MIDDLE IS GROUND (COAX SHIELD)

ADD 1/2" SHRINK TUBING

3. IF CABLE.

CUT COAX TO 11". STRIP ENDS FOR
COAX CONNECTOR & BOARD CONNECTION.
ADD COAX CONNECTOR.

4. PIN 3 & 4 (AGC) ~~CONN~~ CABLE.

~~CUT~~ CUT #22 ZIP CORD (SPEAKER WIRE)
TO 14".

SEPARATE 2" AT EACH END. STRIP FOR
BOARD CONNECTION & TEST CONNECTION.